

PROJECT complete

Marking software



PROJECT complete Marking made easy

Intuitive configuration, intelligent functions, and a customizable user interface: the PROJECT complete software is currently the most innovative solution for straightforward creation of the corresponding markings.





Contents

Easy and convenient creation of markings	4
Interface overview	6
Inserting new material	8
Inputting data	9
Text editing	10
Special characters	12
Automatic sequencing	14
Autofill function	17
Automatic wire marking function	18
Setting the length of endless material	19
Printing	20
Importing data from Excel	21
Inserting graphics	26
Inserting barcodes	30
Changing materials	32
Creating a template	34
Setting up a printer	42
Perfect CAE integration	45
	46

Easy and convenient creation of markings

The software PROJECT complete marking can be used to create your marking easily and conveniently – despite the wide range of different marking materials.

- The areas that can be labled are indicated
- Handling is extremely user friendly
- All printing systems from Phoenix Contact, as well as standard printers can be controlled
- Individual label creation with a template designer



Perfect CAE integration

PROJECT complete marking comes equipped with optimized interfaces to all common CAE programs. With just a mouse click, the software imports all the marking data for your project.

Intuitive software operation

PROJECT complete marking provides you with a new user interface with a configurable 'search function' and dynamic task bars.



The new standard for the control cabinet. More information on pages 46 to 49.



Intelligent functions like the ready-to-use material descriptions automate many planning steps and ensure significant time savings.

Simply Easy

PROJECT complete marking is suitable for all Phoenix Contact marking systems. The integrated template designer allows the user to change label layout and create custom labels designs easily.

Interface overview

The user interface of PROJECT complete marking is based on dynamic ribbon technology, which gives the user a familiar feel to the layout of the application. Functions are grouped into different tabs and depend on the application.

Project tree

The marking material that is associated with a project, including the function and location information, are listed in an overview.



Marking Editor

Working area where the marking material is visible in real and the marking information can be entered manually.

Tabs

The dynamic task bar contains a summary of the functions in tabs. Certain functions only show up in their own tabs in the task bar when they are needed.

Insertion Center

Products can be found by entering the order number or name of material. The live search suggests material descriptions during the input process.



You can add regularly used material descriptions to your favorites list and create a short cut to the

Product information General data on the material is displayed here.

Inserting new material

The initial starting page will display the ability to create a new marking project.



• You may search for material by entering the part number, type description or scroll through the list.



• Using the Insertion Center navigation panel, select your printer (if Insertion Center is not active, go to View and click the insertion center icon).



- Using the list of material associated with your printer, select the required material for your application.
- Double click on the selected material to edit.

Inputting data

The material is ready to use now and you can manually enter your information on the selected material.



• Click on the marker to enter data.



- To enter multiple lines of text on a marker, hold Alt + Enter or use the down arrow on the key pad.
- By hitting Enter or Tab, you will be moved to the next row of markers.

Text editing

PROJECT complete marking provides a fully integrated text editor to adjust the font settings.



• Click "Home" tab (you must highlight the marker before changing font)

		La Congress	A Received II (1997)
regard *	tian free		
2.3	TRAcial N		
	B/U e ^r A-		
	A Mirroring Al Proper		

• Choose font type. Arial is the default.



• Set font size if needed.

and Parks	Arrent	American Line	Intiligence	a Lang Arts _ Lang	100 Ten
njavit 1		Bodoui MT	Cousier New	DESERTS	
1 3 4 5	1	TK isoboli	1		
	-	1	10 C	₹ = ± =	0
	-		00 (1.
	-			43	

• Set font alignment.



Text rotation

Special characters

The working area: special characters offers a large range of characters and symbols for different applications.



· Click on "View".



• Click "Special characters".

Working area: special characters

		PROJECT con	giste - cucking	_		_	_	_	_	
Elling to get D	TONNAR LIER promotion properties	Clainel suntering.	Ritecce. Goormann Ethnope and			+ 1 + 1			- 10,11 - *	
	MOMARK ROLL / ROLL 2.0 / XT	•	71		0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0			0 1 1 0		DESCRIPTION International Adda Add Links Description
	с -		4	(> B +) () [0000	D C C C C C C C C C C C C C C C C C C C	00		DESERVER at parage

• "Special characters"

		Landon Dean Grand Tealmer Land 11 Landon Emil Landon	
Durnh Court	Epice transer secolo	. ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	
	System forts Standard C System res Pric Symbol 1		
	4		SIRGE POTON

• Choose symbols from categories by selecting the tab along the top of the window.



- The drop-down menu opens up other choices under system fonts only. All others have just one type.
- Select the desired symbol.



• Click "Insert", double click, or drag and drop onto marker.

Automatic sequencing

Offers the possibility to create labels based on numeric and alphanumeric sequences.



Click "View".



• Click on "Label numbering".

Working area: Label numbering



Label numbering

	r jana Sina.		CONSIDER
The second		Charl standarding Routher synthes Socialities Socialit	Market Second Second<

• Choose between numbers or letters.



- Select the start value, end value, and increment.
- Enter any alphanumeric prefixes if needed.



• Click "Start".

Label numbering example



Font settings example

		Camic Sona MS	Times New Roman	CTINES 3 TEL Minister	
↓ CC → 100 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	a.	2.44 and 2 seed	[1]	(Canadas) Baranter	
A-1-T3 A-2-T3 (2000) 2 10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		Ţ	CE	Corners p.m.	
		A-1-T3	A-2-T3	(20006) și 111	Den half Beneret Benet Beneret Beneret Beneret Beneret Beneret Beneret Beneret Beneret

- Font style and size
- Text rotation

Special characters and label numbering examples

ant Networks, Ala 21 a	Cansic Sons MS	Times New Roman	COMMON 2 TEL Manager	1
	SM HARE SHARE	12]	(2006) ; ==	
	Ţ	CE	(17900) p mi	
	A-1-T3	A-2-T3		
	A-3-T3	A-4-T3	()	

- Symbol
- Enumeration with the prefix A- and postfix -T3.

Autofill function

This fills the remaining markers with the same content

Only available for labels with multiple rows of markers



• Enter data into the first marker.



· Right click on the first marker and select "Fill".



• The remaining markers are filled with that data.

Automatic wire marking function

Create 360° visibility, ideal for wire marking.



- Enter the data on the wire marker.
- · Make sure the marker is selected as indicated by the green highlight.



• Select "Cable wrap" under the Home tab.



· Data is then automatically repeated in as many rows possible to ensure visibility in all directions.

(Font must be small enough for multiple rows)

Setting the length of endless material

Unit of measurement is metric by default. Change the unit of measure in options.



• Select an endless material. (designated with an "E" in the parentheses)



• Right click on the marker and under "Set material length" type in the desired length. Hit enter to apply.

Printing

After finishing the data input start the printing process.



Click on Print.



• Print manager

Col Date Date Date Date Image Image Image Image Image Image Image Image Image Image Image Image Image Image	G, host sample Phile paraget Martine cample, martine and mart	
Organity Processing Pro	Provide a series Provide All Series Provide	
	Reserved Connects	

• Click "Print" in print manager.

Importing data from Excel

Data can be created in Microsoft Excel (or another source) and imported into PROJECT complete. This requires an initial configuration of the data exchange manager.



• It is possible to import from more than one column.

Start the data exchange manager



· Click "File".



· Click "Data Exchange".

Create a new import configuration



· Click "New".



 Click the Browse button to find the Excel file. (You may have to change to all files to find the Excel file)



· Click "Open".

elect a file and in	ts type.		
Import file: 0 C:\Users	gtwaybri Documents Excel 1 c	əlumn xisx	
File type			
Select the option that a	describes your file best.	Column 1	
O Separated	- characters such as co	WIRE 2	
C Fixed width	- fields have equal wid	WIRE 3	
Excel file	Sheet:	WIRE 5	
Format		WIRE 6 WIRE 7	
Start import in line:	1	WIRE 8	
Line break separator		WIRE 10	
		141RE 12	

· Preview the data.

Define the needed marking material for the application



• Click "Material mapping".



• Click "Enforce default material". The insertion center will automatically pop up.

	Setup mapping of materials found in input data	
	States atest word Party	
	Merristaget sputnet to Aputnet	
of campoon	(And margins (and the second se
ALCO DAMAGE	Column Anipedim	G Number Center
		Servi are
	828.5	
	414E 1	
		THERE AND
	KIM 14 AMARK THERSTOMARK	
	state to ROLL 20	W HWS 22.4 (540) / 16, 100 / 10 / 10 / 10 / 10 / 10 / 10 / 10
	HEAT 1 ALLAY 2	B who 12 (0.44 / AL and the second
	MELAT 5	B AND 12-6-54 PL 10000
	HINKY 5	and the state of t
	MLAT 4	Prest. Mar
	RELAT 8	Deplay name Apro burner
	lant	Output devices THERMORENERING Application Reconnect making
	and a second	Same int

• Select your printer.



• Select the desired material.



· Click "Insert".

File Ho	me Insert Interfaces \	/iew Import Wizard
RunImport	C Reload Input Data	-
Import	Data	
New (1)		
Source	Set 2	als found in input data
Filters and so	rting Run In	nort
Logic tree	MEN	WMS 3,2 (30x5)R / RL / RXL
Condition fiel	d Material le	No Adjustment
Material mappi	Label margins:	0.00

• Click "Run Import".

tie Home h	nert lite	rfaces View				
The Sector	nie.	B / U 9 ▲ + A A Merping A Herping A Herping A Herping A + -	0 - Stretching: E Line thickness: <u>A</u> Wath fector:	10.00 1 0.00 1 1.00 1		paking:
St 1mm (1) - D	Excel 1 colur	n × 1	Port		Tel: Algor	100
Pojective	-	9 × 9	v	VIRE 1	WIRE 2	
=-D	0x53R/RL7	ROL (THERMOMARK ROLL / P	v	VIRE 3	WIRE 4	1
21		-	V	VIRE 5	WIRE 6	
-01			V	VIRE 7	WIRE 8]
-01		2	V	VIRE 9	WIRE 10	
87		P		IRE 11	WIRE 12	
		P	R	ELAY 1	RELAY 2	
10 10		•	R	ELAY 3	RELAY 4]
011		P	R	ELAY 5	RELAY 6	
0.13		P	P	ELAV 7	DEI AV 8	1

• The file has been imported and you are returned to the standard view.

tie Home Insert Interfaces	Ven		
The second secon	Relat +) (5.00 +) ere / U ⊕ ▲ + Mempering Al Proportional Font	Stretoring: 10.00 ° Line thickness: 0.00 ° Wildth factor: 1.00 °	F E L E Rotation F E I I Chespadry
S New (1) - Excel 1 column			II PROVIDENTS
Pojective	* * •	WIRE 1	WIRE 2
	HERMOMARK ROLL / P	WIRE 3	WIRE 4
21	-	WIRE 5	WIRE 6
	P	WIRE 7	WIRE 8
-04	P	WIRE 9	WIRE 10
-8:	P	WIRE 11	WIRE 12
0.0	P	RELAY 1	RELAY 2
-0 10	•	RELAY 3	RELAY 4
		RELAY 5	RELAY 6
0 13			

• You may make any changes as needed and print the project.

Inserting graphics

Project complete supports any image file (.jpg, .tif, .gif, .bmp, etc.).

Image: Second	
Cil Text feld. Ellose. Rift Earcode. Actangle. A Polyline. Vector element. — Line. Objects Shapes	ne Insert Inte
Ponyreject9 Conserved UC-IM-P (60-10) (BLUEMARC/ BLUEMARC) UC-IM-P (60-10) (BLUEMARC/ BLUEMARC)	CREctangle

• Select desired material and click "Insert" at top. Click on material.



· Click "Bitmap".

n ▲ 10 10 0 1 Tana Tana Marka san Garage Charles Bages	HERIZ complete - molecy	
aloneret Un.		
Property -		
B 1 B ⊂ ork-spice Brighter Frighter B	CONTRACT CONTRACT	

• Draw a box for estimated size of graphic.

Pure black and white is recommended for best print quality (unless using the Bluemark ID color printer).

A to represent to represen	HEED on phe	e nakog ⊈ hjernogitit S - 1 \$ + het t. Innina Signa * Nedda	
D D D D D D D D D D D D D D D D D D D		Image: Section 1 Term Image: Section 2 Construction 2 Image: Section 2 Construction 2	Ben under an and a second and a

• In the pop-up window, browse to select graphic.



• Use the yellow grab points for resizing the graphic.

Re-sizing an positioning graphics

For specific requirements.

A grid helps visually lay out the graphic on the label.



- Need to be in "View".
- Click in marker area to use the visual grid and snap to grid (graphic must be highlighted for this menu to be visible).



• Toggle "Use grid" and "Snap to grid" on or off, depending on preference.



• "Use grid" and "Snap to grid" turned on.

Layout tab

Layout	Shape Form	at Shape				
Y Top:	8.00 (5.00 (Email:	43.00 (a [mm]	Frame thickness: Color: Line type: Frame	0.70 ; [mm]
		La K Lef	yout k			

• Click "Layout" and input specific dimensions for width and height.

X Left: 8	5.00 C Height:	43.00 (mm)	Frame thickness: 0.70 ; If Color: •	nm]
Position		Size	Frame	

• To change the width and height independently, click the chain icon to break the link.

• The frame option outlines the graphic. Adjust the line thickness and choose line type from the dropdown.

Inserting barcodes

PROJECT complete marking offers a lot of different barcode types (Code 39/128/93, EAN 8/13/128, ISBN, DataMatrix, QR Code, etc.)



• Click to highlight the marker.

Ter Hume Ball D Galamap. Caref Red., References Line. Objects State	Report.	
Presentent =	Home Incent COMAC UC EMLP (60.30) With Water	
	tor elementa - Line.	

· Click "Insert" and select "Barcode".

Working area: barcode

Insertion Center	₽ ×	Barcode		4 ×
Searchterm	× *	Barcode type:	Code 39	~ 0
-		Data:	254436	
		Font size adjustment:		
BILLENAADY		- Code 39 Properties	-	
CLED		Text position:	Top center	~
		Borden	None	

• Use dropdown to choose barcode type.



• Use the mouse to draw a box where you want the barcode.



• Type in the information for the barcode into the white area and hit enter.



• Use the yellow grab points to resize barcode if needed.

Changing materials

This wizard is helpful for changing the material type of an existing project.



• Click the "Home" tab.



• Click "Change material".



• Then click "Select material".

You can change the material to any type regardless of material type or printer.



· Choose material and click "Insert".



Click "OK".

Creating a template

PROJECT complete offers the template creation that is used to design custom labels on existing material.



• Here is an example of a template for a machine type label.

Inserting text fields

•	Phoenix Phoenix
1990	PART NUMBER
0 EMM40	
AC NORT	NOTES
	STATEM

• Permanent text field: for text that you wish to remain constant. i.e same on every label, titles like Date/Part number etc.



• Dynamic data input: where the data can be edited. e.g the actual date.

Starting a template

a i i i i i i i i i i i i i i i i i i i	- 2.20	. Stretching:
Paste B / U O A - Paste Urroring Al Proport	ional Font	Line thickness:
File		

· Click "File".

And and	T Arial	- 2.20	tretchin
G	Nou		
IC New	Create a new l	project	
tilië Open	create a new	project	
Templates	D: New	Riew template	
5). Data Exchance		Dr.	

• Click "New" and "New template".



• Choose printer and material.



- Highlight template.
- Click "View tab" and choose "Snap to grid" and "Use grid".



• Click "Insert" and select "Text field".



• Insert box the estimated size of text field (can be adjusted later).

2 Environg protection	Ditabel group: The set of the set		1		
ENLP 60x30 PxC Mack	*				
Temphald exposer Concept Con	e	Properties	PANE Assem Date: Date: Date:	I BACK PLANE	EXECUTION AND A CONTRACT OF A
		-			

• For indexing through text fields, you need to click on "Properties" to access the text field name and number.



· Click on the area to be protected.



 Click "Content Protection" and "Location Protection". This locks the graphics and text fields so they cannot be changed.

File Hone Inset	Interfaces View	Leyout	Format Shape	Properties
Printing protection	Text field name:	Text field	•	
Location/size protection	TE Index	3 4		
All Content Protection	mport accumulation	1 👽	1	
Protection Options	ldent/	fcation		
US-ENLP 100400 ×				
Template explorer	9 x 🗖		7.00	Layout
Constant State Constant		SI	REC COM PART. ERIAL NUI D	Text field 3 V 1 V fication 3 2

• Click in the text field and give it a name (optional), hit enter. Give it a number in the index box and select the checkmark.



• Indexing example, 1, 2, 3

Saving the created template



• Click "File", then click "Save as".



• Name the template and click "Save".

Export template

Exporting the template allows you to save the template outside of the PROJECT complete library for saving to other computers.

G)	Template	c				
D	Nex	Manage template	3 tes				
s	Qpen	manage compa				_	
	Templates	Counterpase	± in exception	🚊 fane tomptoto at	Disportungia	(A teasterpare	B Deteta tampina
8	Data Exchange		1	-		-	
4	50-10		- 0	inen			
2	Lave gs			p.e.r.			
10	Initial Configurations		-				
0	Adve Printers		Ti 🔟	emplates			
0	Options		and the second				
Ø	Support		D 0	ata Exchai	ne		
Det.			e .	oto excito			
				-			

• Click "File", "Templates", Export template.

G D here B Down	Template Manage templa	S tes				
() Templature	Counterplate	the template	2 fave tomptate at	Disportungen	(A fastinger	Deteta tanyata
🔂 Cata Exchange		1	-		2	
A 10-4		0	pen			
2 Lave gs						
Eő hinter Configurations		-	and the second			
12 Active Printers			emplates			
O Options			-			
() Support		D D	ata Excha	ne		
Let .						
			-			

- Select the template to be exported.
- Click "Export template" and save file in desired location.

G	Templates				
3 1000	Management				
gpen .	manage templates	/			
Terrylates	E Opertoryphie 2	Saranger .		a Gatestanum	
Data Exchange		1			×
10.00		-			
Lave gs			Export		3
Neter Configurations			4	-	_
Active Pretars					
Options					
Support					
e		3	anglate rame (D.S.F.A. 100)	INCREM.	
				- Dev	Case

• Select the template to be exported and click "Export".

Import template

Importing templates adds templates to the PROJECT complete library that were designed on another computer.

G	Tomplete					
D New	Manage template	r5 ates				
Si Open				_		
Templates	Counterplate	the second	2 feetemptotest	Department	(a figottergan	B. Deservice years
🔂 Data Exchange			-			
A 10-1				•0		
A Lavegs		🧉 Ope	en			
10 Initial Configurations						
ET Achie Netlers		-	and a second			
O Options		ien Ten	iplates			
() Support	N N	Contraction of the second		7		
Lot.		Data	a Exchang			
			1			

• Click "File", "Templates" and select "Import template".



• Select previous exported template and open to view from new location.

Setting up a printer

Note: Make sure you have the printer driver installed before completing this step.



• Click "File", "Printer configurations", then click "New" and select printer.

O Printer Configur	ations
Manage Printer Configuratio	n(s)
Discharge Jim Jim Limit Limit THERMOMARK ROLL THERMOMARK ROLL THERMOMARK ROLL THERMOMARK ROLL	Sare Mathonik da n Mar Anno Canada Canada
al Active Annexes Instatrial Calibration O options O fiscent Der	Applete Installation Mexico Mex

- Then click drop-down box and select the printer.
- Your printer is now set up as an output device to print.

Setting print alignment and speed

Note: Make sure you have the printer driver installed before completing this step.



• Click "File", "Printer configurations", choose the printer.



 In printer calibration choose the material that needs to be aligned. Double click under the "Offset X" or "Y" depending on how the alignment needs to be adjusted.



• Click up or down arrows to make adjustments.

Cutter options

For material that is on an endless roll.

Note: Make sure you have the printer driver installed before completing this step.



• In the printer configuration area, click "Print calibration", choose the material and then double click the perforation mode to activate the drop down menu. Then select the option you require.

Perfect CAE integration

PROJECT complete marking comes equipped with optimized interfaces to all common CAE programs. With just a click of the mouse, the software imports the data from electrical plans and automatically creates the corresponding marking solutions.



PROJECT complete planning has bidirectional interfaces to CAE programs

The bidirectional interface allows you to send terminal strips from CAE programs to PROJECT complete planning.

You can make the following changes to your terminal strips in PROJECT complete planning:

- 1. Replace terminals
- 2. Add accessories
- 3. Replace wire bridges with jumpers

After the terminal strips have been edited, the changes are exported to the CAE programs.



CAE program





PROJECT complete planning

COMPLETE line – The comprehensive solution for your control cabinet

COMPLETE line is a system comprising technologically leading and coordinated hardware and software products, consulting services, and system solutions that help you optimize your processes in control cabinet manufacturing. Engineering, purchasing, installation, and operation become significantly easier for you.





Your advantages in detail



Comprehensive product portfolio

With COMPLETE line, we offer a complete product portfolio of technologically leading products.



Intuitive handling

Thanks to the simple, intuitive handling of the coordinated hardware components, you will save time during installation, startup, and maintenance.



Save time throughout the entire engineering process The PROJECT complete planning and marking software supports the entire process of control cabinet manufacturing.



Reduced logistics costs

Reduced variety of parts, thanks to standardized marking, bridging, and testing accessories.



Optimized processes in control cabinet manufacturing COMPLETE line supports you, from engineering through to manufacturing, in designing your control cabinet production as efficient as possible.



The new standard for the control cabinet

Discover the extensive COMPLETE line product portfolio and find out more about COMPLETE line and your comprehensive solutions for the control cabinet.

phoenixcontact.com/completeline

Notes		



phoenixcontact.com

